


FirstG

Quick Start Guide



1 Insert SIM card



Micro SIM



Mini SIM




Micro SIM



Nano SIM


2 Turn on FirstG

- Press and hold the power button for 3 second
- When the light of  stays on, it means successful connection.



3 Connect Wi-Fi

- Find the Wi-Fi name and password at the back of FirstG (or inside)
- Connect your mobile device in Wi-Fi setting



4 Unlock PIN

- If SIM card is set to PIN safety mode, connect to WiFi, visit 192.168.43.1 which will direct to unlock PIN webpage, enter correct PIN code to unlock



5 Set APN

- If there is no connection after completion of preceding steps, you have to add APN manually.

- **Settings** → **Network settings** → **APN settings**

→ **Add manually** enter APN of your SIM card operator, save and use.



Manage My Device

Web: 192.168.43.1

Username: admin

Password: admin